

VCS3000

Reference #	Part #	Description	Quantity Required
1	50001310	PANEL BOTTOM ASSEMBLY - H3	1
2	50001317	LEG H3 - FINAL ASSEMBLY	4
3	50001995	FRONT PANEL H3 - BLACK S/S	1
4	50000090	CASTER	4
5	50001462	BASE ASSEMBLY H3	1
6	50001279	LID ASSEMBLY - REAR BLK H3	1
7	50001300B	FLASH TUBE H3	1
8	50001302	SUPPORT GREASE PAN	2
9	50000892	GASKET BURNER HBQ	3
10	50003133	BURNER ASSEMBLY - Long Wire	3
11a	50001439	VALVE ASSEMBLY H3 NG	1
11b	50001438	VALVE ASSEMBLY H3 LP	1
12	50001432	CONSOLE ASSEMBLY	1
13a	50000804	REGULATOR	1
13b	50000198	HOSE NG - 12 FT	1
14	50000355	HARDWARE - LID SET	1
15	50001996	LID ASSEMBLY - FRONT CHARCOAL S/S	1
16	30005548K	GREASE PAN - H3	1
17	50001314	COOK GRATES - H3 ENAMEL	2
18	50001327	BEZEL	3
19	50003003	KNOB - H STYLE	3
20	50000777	HEAT PLATE - SS	3
21	50001311	WARMING RACK - H3 ENAMEL	1
22	50001845	GREASE CUP	1
23	50001319	GREASE CUP HOLDER - H3	1
24	50000431	ELECTRODE - MAIN SHORT	1
25	91D0108	ELECTRODE WIRE MAIN LONG - NEED 91D0107 FOR ELECTRODE	2
56	91D0107	ELECTRODE ONLY - MAIN	2
26	50000365	LID BUMPER SET (6)	4
27	50001418	SHELF SUPPORT L BLACK - H/VC	2
28	500001419	SHELF SUPPORT R BLACK - H/VC	2
29	50001482	FRONT LIP - H3	1
30	50000816	IGNITOR KIT	1
31b	50001509	SHELF TOP	2
32	50001390	HARDWARE BAG	1
35	50002019	SIDE PANEL - H3 BLACK	2
N/S	VCDC3S	GRILL COVER - CAN SUB VCS08C3	1