

VCS300SS_ES

Reference #	Part #	Description	Quantity Required
1	91D0132	BURNER MAIN LONG ELECTRODE	2
2	91D0133	BURNER MAIN SHORT ELECTRODE	1
3	50000892	BURNER GASKET	1
4	50001300B	FLASH TUBE H3	1
5	50004295	CONSOLE ASSEMBLY VC 3 BURNER	1
7	50002533	IGNITOR PLATE	1
8	50002394	IGNITOR KIT 4 POLE CHROME	1
9	91D0111	HOSE REGULATOR LP	1
12	50004325	CONTROL KNOB - LONG STEM	3
13	50003853	WIRE HARNESS 3 BURNER	1
15	91D0136	CONDIMENT TRAY LEFT	1
16	91D0137	CONDIMENT TRAY RIGHT	1
17	30005448K	SMOKER BOX KIT	1
20	91D0110	SHELF KIT LEFT	1
21	91D0141	SHELF KIT RIGHT - PRE 2010 ONLY	1
21	20300401	SHELF KIT RIGHT - 2010 PRODUCTION	1
22	50004320	TOWEL BAR	2
24	91D0130	COVER S/B ASSEMBLY - 304SS - PRE 2010 ONLY	1
28	50000777	HEAT PLATE - SS	3
31	50004318	COOK GRATES	2
32	50001668	WIRE CONNECTOR SIDE BURNER	1
33	50004333	DOOR UPPER BRACE 3 BURNER - SS - PRE 2010	1
33	20300588	DOOR UPPER BRACE 3 BURNER - SS - 2010 PRODUCTION	1
33a	91D0115	DOOR UPPER BRACE 3 BURNER - BLACK	1
34	50002033	MAGNET SNAP IN	2
35	50001845	GREASE CUP	1
36	20300395	BEZEL FOR TEMPERATURE GAUGE - 2010	1
37	50004230	BACK PANEL BLACK 3 BURNER	1
38	50002490	SNAP BUSHING 2IN.	1
40	50004331	DOOR ASSEMBLY 3 BURNER - SS -PRE 2010	1
40	20300386	DOOR ASSEMBLY 3 BURNER - SS - 2010 PRODUCTION	1
40	91D0119	DOOR ASSEMBLY 3 BURNER - BLACK	1
41	50004204	DOOR HANDLE CURVED -128mm	2
42	50004343	SIDE PANEL RIGHT - SS - PRE 2010	1
42	20300389	SIDE PANEL RIGHT - SS - 2010 PRODUCTION	1
42	91D0117	SIDE PANEL RIGHT - BLACK	1
43	50004344	SIDE PANEL LEFT - SS - PRE 2010	1
43	20300390	SIDE PANEL LEFT - SS - 2010 PRODUCTION	1
43	91D0118	SIDE PANEL LEFT - BLACK	1
48	50004257	GREASE TRAY 3 BURNER	1
49	50004165	REAR LID ASSEMBLY 3 BURNER	1
50	91D0104	WARMING RACK 3 BURNER	1

51	50004400	FRONT LID ASSEMBLY S/S 3 BURNER - PRE 2010	1
51	20300391	FRONT LID ASSEMBLY S/S 3 BURNER - 2010 PRODUCTION	1
51a	50004411	FRONT LID ASSEMBLY MICA BLACK 3 BURNER - PRE 2010	1
51a	20300392	FRONT LID ASSEMBLY MICA BLACK 3 BURNER - 2010 PRODUCTION	1
52	50000355	HARDWARE LID SET	1
53	50000365	LID BUMPER (SET OF 6)	1
54	50004373	LOGO ASSEMBLY - PRE 2010	1
54	20300393	LOGO ASSEMBLY - 2010 PRODUCTION	1
55	50004223	TEMPERATURE GAUGE - PRE 2010	1
55	20300394	TEMPERATURE GAUGE - 2010 PRODUCTION	1
56	91D0108	ELECTRODE WIRE MAIN LONG - NEED 91D0107 FOR ELECTRODE	2
56	91D0107	ELECTRODE ONLY - MAIN	3
57	91D0109	ELECTRODE WIRE MAIN SHORT - NEED 91D0107 FOR ELECTRODE	1
58	50000115	ELECTRODE SIDE BURNER	1
59	50001046	VALVE SIDE BURNER LP	1
59a	50001045	VALVE SIDE BURNER NG	1
60	50000113	KNOB- SIDE BURNER VALVE	1
63	91D0112	CONNECTOR HOSE NG	1
64	50000198	NATURAL GAS HOSE 12FT.	1
66	50004272	BATTERY SHROUD ASSEMBLY	1
68	50004404	HANDLE GRIP SET	1
69	50004384	ADJUSTABLE LEVELING GUIDE (SET OF 4)	1
70	50004255	CASTER 3IN 1 1/4IN. SWIVEL PLATE	2
71	50004256	CASTER 3IN 1 1/4IN. SWIVEL PLATE W/BRAKE	2
73	91D0140	SIDE SHELF HARDWARE BAG	1
74	20300623	HINGE 20 GA. 20.5IN. - SS	2
74	20300624	HINGE 20 GA. 20.5IN. - BLACK	2
76	50002888	CYLINDER RETAINER LP ONLY	1
77	50004269	NYLON CABLE CLAMP 9/16IN.	1
78	50004667	NYLON CABLE CLAMP 3/4IN.	1
79	91D0155	HARDWARE BAG CASTERS	1
80	50004258	GREASE CUP HOLDER	1
82	50004328	BEZEL ASSEMBLY - LONG STEM	3
83	50004417	UTENSIL HOOK	3
85a	20303019	VALVE STRAIGHT MANIFOLD ASSEMBLY LP	1
85a	50004136	VALVE STRAIGHT MANIFOLD ASSEMBLY NG	1
88	50003110	BATTERY CASE	1
89	50002914	SNAP BUSHING 3IN.	1
91	50004234	CORNER POST - SS - PRE 2010	4
91	20300399K	CORNER POST - SS - 2010 PRODUCTION	4
91a	91D0114	CORNER POST - BLACK	4
92	20300396	CART FRONT PANEL	4
93	50004229	CART BOTTOM	1
94	20300397	CART BOTTOM SIDE PANEL - 2010 PRODUCTION	1
N/S	91D0003	USERS GUIDE	1

N/S	91D0002	VCS300/400 ASSEMBLY MANUAL	1
N/S	20300419	VCS300/400 PARTS LIST	1
N/S	VCS08C3	COVER 3 BURNER (OPTIONAL)	1
N/S	20300525	CONVERSION KIT - LP TO NG	0
N/S	20300526	CONVERSION KIT - NG TO LP	0

Woodmanspartsplus