

VCS3507BI

Reference #	Part #	Description	Quantity Required
1	50003165	BASE ASSEMBLY	1
2	50002104F	CONSOLE HEAT SHIELD	1
3	50000816	IGNITOR KIT	1
4	50004073	CONSOLE	1
5	50001953B	BOTTOM COVER	1
6	50001947B	BRACKET RIGHT	1
7	50002106	BRACKET LEFT	1
8	50001954B	REAR COVER	1
9	50001955B	GREASE PAN	1
10	50001956B	GREASE PAN FRONT	1
11	50003623B	CONSOLE REINFORCEMENT	1
12	30005787	REAR LID ASSEMBLY (REQUIRES PART 50000355)	1
13A	50003170	VALVE, MANIFOLD ASSEMBLY (LP)	1
13B	50003171	VALVE, MANIFOLD ASSEMBLY (NG)	1
14A	50000804	REGULATOR ASSEMBLY (LP)	1
14B	50000198	HOSE NG - 12 FT	1
14C	50000915	CONNECTOR HOSE (NG)	1
15	50003648	KNOB BEZEL	4
17	50003133	BURNER ASSEMBLY - INCLUDES ELECTRODE AND WIRE	3
18	50000892	BURNER GASKET	3
19	50001300B	FLASH TUBE	1
20	50003500	ROTISSERIE ASSEMBLY	1
21	50003473	ROTISSERIE ELECTRODE WIRE	1
22A	50001992	TUBE & ORIFICE ASSEMBLY (LP)	1
22B	50002018	TUBE & ORIFICE ASSEMBLY (NG)	1
23	50003472	ROTISSERIE ELECTRODE - INCLUDED IN PART 50003462.	1
24	50000777	HEAT PLATE - SS	3
25	50000355	PIVOT PIN & BOLT SET - SEND WITH LID ASSEMBLY	1
26	50004015	FRONT LID ASSEMBLY S/S (REQUIRES PART 50000355)	1
26	50004016	FRONT LID ASSEMBLY BLACK (REQUIRES PART 50000355)	1
28	50000365	LID BUMPERS (SET OF 6)	1
29	50001311	WARMING RACK (ENAMEL)	1
30	50003765	COOKING GRIDS (PACK OF 2)	1
32	50002102	ROTISSERIE KIT	1
33	50004069	HANDLE GRIP SET	1
35	50001326	ROTISSERIE SPIT ROD	1
36	50003981	KNOB ASSEMBLY (GRAY)	4
36	50004109	KNOB SPRING CLIP (PACK OF 6)	1
37	50000313	DOOR HANDLE	1
38	50002105	HARDWARE BAG	1
39	50000672	FLEXIBLE CONNECTOR 28	1
40	91D0108	ELECTRODE WIRE MAIN LONG - NEED 91D0107 FOR ELECTRODE	2
40A	91D0107	ELECTRODE ONLY - MAIN	2

41	50000431	ELECTRODE MAIN SHORT	1
42	50001643	TEMPERATURE GAUGE - SUBS to 20300395 & 20300394	1
N/S	50004014	LOGO - VC Grills	1

Woodmanspartsplus