

VCS4005\_C

REF #	Part #	Part Description	QTY
1	50003882	BASE ASSY	1
2	50001844	SUPPORT, GREASE PAN	2
24	50001011	IGNITOR PUSH BUTTON	1
25	50002533	IGNITER PLATE	1
26	50001619	IGNITER MODULE - Push button not included	1
27	50003898	WIRING HARNESS	1
28	50003002	BEZEL ASSEMBLY - BACKLIT	5
29	50003003	KNOB ASSEMBLY - BACKLIT	5
30	50003514	REAR LID ASSY - Also send p/n 50000355.	1
31	50003069	FRONT LID ASSY - Also send p/n 50000355.	1
32	50001643	TEMPERATURE GAUGE	1
33	50000642	HANDLE GRIP SET - CHARCOAL	1
34	50000365	LID BUMPERS (SET OF 6)	1
35	50000355	PIVOT PIN & BOLT SET Send with lid assembly	1
36	50000802	WARMING RACK	1
37	50003043M	SIDE BURNER ASSY	1
38	50003106	SHELF LIGHT ASSEMBLY	1
39	50003116	ROTISSERIE KIT	1
40	50000161	ROTISSERIE MOTOR	1

VCS4005\_C

41	50000286	ROTISSERIE SPIT ROD	1
42	50000115	SIDE BURNER ELECTRODE	1
43	50001044	SIDE BURNER - BURNER	1
44	50000113	SIDE BURNER CONTROL KOB	1
45	50001046	SIDE BURNER VALVE	1
46	50000070	SIDE BURNER IGNITOR KNOB	1
47	50000111	SIDE BURNER IGNITER - ROTARY 2 TERM	1
48	50001035	SIDE BURNER GRATE (BLACK)	1
49	50003304	CONDIMENT TRAY - LEFT	1
50	50003282B	CONDIMENT TRAY - RIGHT	1
51	50003333	SHELF, LEFT	1
52	50003330	SHELF, RIGHT	1
53	50003314	FRONT TABLE SUPPORT ASSY - RIGHT	1
54	50003315	FRONT TABLE SUPPORT ASSY - LEFT	1
55	50001418	REAR TABLE SUPPORT - LEFT	1
56	50001419	REAR TABLE SUPPORT - RIGHT	1
57	50003059	SIDE BURNER LID ASSY	1
58	50003011	UTENSIL HOOKS (SET OF 3)	1
59	50001845	GREASE CUP	1
60	50003068	CASTER 3, X 7/8	4
61	50002888	CYLINDER RETAINER - LP MODELS ONLY	1
62	50003198	STABILIZER BRACKET ASSEMBLY	1

VCS4005\_C

63	VCDC4S	DELUXE BBQ COVER VCS4005	1
3	50003320	DOOR ASSEMBLY	1
4	50003322	DOOR FACIA	1
5	50003208	HANDLE DOOR ROUND (IF EQUIPPED)	1
6	50000313	HANDLE DOOR DELUXE (IF EQUIPPED)	1
7	50001842B	GREASE PAN	1
8	50000879	FLASH TUBE	1
9	50000892	BURNER GASKET	4
10	50003133	BURNER ASSY WITH LONG ELECTRODE	2
11	50003100	BURNER ASSY WITH SHORT ELECTRODE	2
12	50000431	ELECTRODE - MAIN - SHORT	2
13	50000523	ELECTRODE - MAIN - LONG	2
14A	50003583	VALVE ASSY - LP	1
14B	50003584	VALVE ASSY - NG	1
15A	50002900	S. BURNER HVR LP	1
15B*	50002901	S. BURNER HOSE, VALVE NG	1
16	50000777	HEAT PLATE (S. STEEL)	4
17	50001226	COOKING GRIDS (ENAMEL) - SET OF 3	1
18	50001416	ROTISSERIE BURNER HOUSING	1
19	50000047	ROTISSERIE BURNER	1
20A	50001415	ROTISSERIE GAS TUBE - LP	1
20B	50001428	ROTISSERIE GAS TUBE - NATURAL	1

VCS4005\_C

21	50003129	ROTISSERIE ELECTRODE	1
22	50003881	CONSOLE (PRINTED) VC4005 + ROTISSERIE	1
23	50003319	CONSOLE REINFORCEMENT	1

Woodmanspartsplus