

VCS401SS_ES

Reference #	Part #	Description	Quantity Required
1	91D0132	MAIN BURNER - LONG WIRE	2
2	91D0133	MAIN BURNER - SHORT WIRE	2
3	50000892	MAIN BURNER GASKET	4
4a	50000879	FLASH TUBE	1
5	91D0150	CONSOLE W/RIVNUT ASSEMBLY	1
6	50002788	IGNITOR PUSHBUTTON	1
7	50002533	IGNITOR PLATE	1
8	50001619	IGNITOR MODULE ASSEMBLY	1
9	91D0111	HOSE REGULATOR - LP	1
10	50003002	BEZEL - SHORT STEM	2
11	50003984	CONTROL KNOB - SHORT STEM	2
12	50004325	CONTROL KNOB - LONG STEM	3
13a	50004266	WIRE HARNESS	1
14	20300400	VC LIGHT KIT	1
15	91D0136	CONDIMENT TRAY LEFT	1
16	91D0137	CONDIMENT TRAY RIGHT	1
17	30005448K	SMOKER BOX KIT	1
19	20300520	ACCESSORY SHELF	1
20	91D0110	LEFT SHELF ASSEMBLY	1
21	20300401	RIGHT SHELF ASSEMBLY	1
22	50004320	TOWEL BAR	1
27	50003473	ROTISSERIE ELCTRODE WIRE	1
28	50000777	HEAT PLATE - SS	4
29	50004143	TUBE & ORIFICE ASSEMBLY ROTIS - 1.15mm - LP	1
29a	50004144	TUBE & ORIFICE ASSEMBLY ROTIS - NO.55 - NG	1
N/S	50003474	CLIP FOR TUBE AND ORIFICE	1
30	50003500	ROTISSERIE BURNER ASSEMBLY	1
31	30005363	COOK GRATE	3
33a	20300404	DOOR UPPER BRACE 3B - SS	1
33c	91D0116	DOOR UPPER BRACE 3B - BLACK	1
34	50002033	MAGNET SNAP IN	2
35	50001845	GREASE CUP	1
36	20300395	BEZEL - TEMPERATURE GAUGE	1
37	50004232	CART BACK PANEL BLACK 4 BURNER	1
38	50002490	SNAP BUSHING 2IN	1
39	20300410	BOTTOM DOOR MAGNET	2
40a	20300402	DOOR ASSEMBLY RIGHT - SS	1
40c	20300402	DOOR ASSEMBLY LEFT - SS	1
40e	91D0121	DOOR ASSEMBLY RIGHT - BLACK	1
40g	91D0121	DOOR ASSEMBLY LEFT - BLACK	1
41	50004204	DOOR HANDLE CURVED -128mm	2
42	20300389	SIDE PANEL RIGHT - SS	1
42a	91D0117	SIDE PANEL RIGHT - BLACK	1

43	20300390	SIDE PANEL LEFT - SS	1
43a	91D0118	SIDE PANEL LEFT - BLACK	1
48a	20304860	GREASE TRAY	1
49a	50004168	REAR LID ASSEMBLY	1
50a	20302811	WARMING RACK 4 BURNER	1
51	20300405	FRONT LID ASSEMBLY - SS	1
51a	20300406	FRONT LID ASSEMBLY - MICA BLACK	1
52	50000355	LID HARDWARE SET	1
53	50000365	LID BUMPER SET	1
54	20300393	LOGO ASSEMBLY	1
55	20300394	TEMPERATURE GAUGE	1
56	91D0108	LONG ELECTRODE WIRE	2
57	91D0109	SHORT ELECTRODE WIRE	2
58	91D0107	IGNITOR ELECTRODE	4
63	91D0112	CONNECTOR HOSE - NG	1
64	91D0126	12 FOOT HOSE - NG	1
65	91D0134	ROTISSERIE KIT - w/o spit rod	1
66	50004272	BATTERY SHROUD ASSEMBLY	1
67	91D0131	ROTISSERIE MOTOR	1
68	50004404	CURVED HANDLE GRIP SET	1
69	50004384	ADJUSTABLE LEVELLING GLIDE (SET OF 4)	1
70	50004255	CASTER 3IN. - 1 1/4IN SWIVEL PLATE	2
71	50004256	CASTER 3IN. - 1 1/4IN SWIVEL PLATE W/BRAKE	2
72	50003472	ROTISSERIE ELECTRODE	1
73	91D0140	SIDE SHELF HARDWARE BAG	1
74	20300623	HINGE 20.5 IN - SS	2
74a	20300624	HINGE 20.5 IN - BLACK	2
75a	20300398	SPIT ROD 29IN	1
76	20002888	CYLINDER RETAINER - LP	1
77	50004269	NYLON CABLE CLAMP 9/16	1
78	50004667	NYLON CABLE CLAMP 3/4	1
79	91D0155	HARDWARE BAG CASTERS	1
80	50004258	GREASE CUP HOLDER	1
82	50004328	BEZEL ASSEMBLY - LONG STEM	2
83	50004417	UTENSIL HOOK	3
84	50004310	SPIT ROD STORAGE BRACKET	2
85	20302816	VALVE MANIFOLD ASSEMBLY - LP	1
85a	20302817	VALVE MANIFOLD ASSEMBLY - NG	1
86	50000399	SUPPORT ROTISSERIE SPIT ROD	1
87	50004275	ROTISSERIE MOTOR BRACKET	1
88	50003110	BATTERY CASE	1
89	50002914	SNAP BUSHING 3IN	1
90	50000287	ROTISSERIE FORK KIT	1
91	20300399K	CORNER POST SS	4
91a	91D0114	CORNER POST BLACK	4

92	20300396	CART FRONT PANEL	1
93	50004229	BOTTOM PANEL	1
94	20300397	CART BOTTOM SIDE PANEL	1
N/S	30005463	4 BURNER GRILL COVER	1
N/S	20300524	CONVERSION KIT - NG TO LP	1
N/S	20300523	CONVERSION KIT - LP TO NG	1

Woodmans Parts Plus