

VCS423SS

Reference #	Part #	Description	Quantity Required
1	30005708K	FRONT LID ASSEMBLY - SS	1
2	30005707	LOGO ASSEMBLY	1
3	20300394	TEMPERATURE GAUGE	1
4	20300395	BEZEL FOR TEMPERATURE GAUGE	1
5	30005630	CURVED HANDLE GRIP SET	1
6	50000355	HARDWARE LID SET	1
7	50000365	LID BUMPER SET (6)	1
8	30005711K	REAR LID ASSEMBLY	1
9	30005837	WARMING RACK	1
10	50005363	COOK GRATES	3
11	50000777	HEAT PLATE - SS	4
12	30005798K	GREASE PAN	1
13	50001845	GREASE CUP	1
14	50004258	GREASE CUP HOLDER	1
15	91D0132	BURNER MAIN ANGLE ASSEMBLY - INCL. ELECTRODE AND WIRE	4
16a	20302816	VALVE MANIFOLD ASSEMBLY - LP	1
16b	20302817	VALVE MANIFOLD ASSEMBLY - NG	1
17a	20300647	ORIFICE LP - SEAR BURNER	1
17b	20300766	ORIFICE NG - SEAR BURNER	1
18a	50004145	TUBE & ORIFICE ASSEMBLY 4 BURNER - LP	1
18b	50004146	TUBE & ORIFICE ASSEMBLY 4 BURNER - NG	1
19	91D0108	ELECTRODE WIRE - MAIN	4
20	91D0107	ELECTRODE ONLY - MAIN	4
21	50000892	BURNER GASKET	4
22	50000879	FLASH TUBE	1
23	30005717K	CONSOLE w/RIVNUT ASSEMBLY	1
24	50002788	IGNITOR PUSHBUTTON	1
25	50002533	IGNITOR PLATE	1
26	50001619	IGNITION MODULE - 8 POLE	1
27	50003002	BEZEL ASSEMBLY - BACKLIT	5
28	50003984	KNOB	5
N/S	30005426K	BATTERY SHROUD ASSEMBLY	1
29	50003110	BATTERY CASE	1
31	91D0134	ROTISSERIE KIT - w/o spit rod	1
32	91D0131	ROTISSERIE MOTOR ONLY	1
33	50004840	ROTISSERIE FORK KIT	1
34	50000399	SPIT ROD SUPPORT BRACKET	1
35	50003500	ROTISSERIE BURNER ASSEMBLY	1
36	50003472	ROTISSERIE ELECTRODE	1
N/S	50003474	CLIP FOR TUBE AND ORIFICE	1
37	50004275	ROTISSERIE MOTOR BRACKET	1
38	20300398	SPIT ROD 29IN	1
39	30005427K	SPIT ROD STORAGE BRACKET	2

40	50004266	WIRING HARNESS	1
41	50003473	ROTISSERIE ELECTRODE WIRE	1
42	91D0111	HOSE REGULATOR - LP	1
43	91D0112	CONNECTOR HOSE - NG	1
44	20302809	HOSE PLUG	1
45	50002384	12 FOOT HOSE - NG	1
47	50002490	SNAP BUSHING 2IN - NG Only	1
48	50002914	SNAP BUSHING 3IN	1
49	20304882	SHELF KIT RIGHT	1
50	30005410K	SHELF KIT LEFT	1
51	91D0140	HARDWARE BAG SIDE SHELF	1
52	91D0136	CONDIMENT TRAY LEFT	1
53	91D0137	CONDIMENT TRAY RIGHT	1
54	50004320	TOWEL BAR	2
55	50004417	UTENSIL HOOK	3
56a	20304422	SEAR BURNER ASSEMBLY - LP	1
56b	20304423	SEAR BURNER ASSEMBLY - NG	1
57	20301000	SEAR BURNER TOP COVER	1
58	20301001	SEAR BURNER LID KNOB	1
59	20300645	SEAR BURNER GREASE TRAY	1
N/S	20300626	SEAR BURNER IGNITOR KIT	1
60	20300625	SEAR BURNER ELECTRODE	1
61	20300629	SEAR BURNER VALVE	1
N/S	20300647	SEAR BURNER NOZZLE (INJECTOR) ASSEMBLY LP	1
N/S	20300766	SEAR BURNER NOZZLE (INJECTOR) ASSEMBLY NG	1
62	20304427	KNOB SEAR BURNER VALVE	1
63	20300641	SEAR BURNER ONLY	1
64	20300630	SEAR BURNER COOK GRATE	1
69	20300400	VC LIGHT KIT	1
N/S	20300413	DOOR UPPER BRACE	1
70	50002033	MAGNET SNAP IN	4
71	30005723K	DOOR ASSEMBLY - SS	2
n/s	20300623	HINGE 20 GA. 20.5IN. - SS	2
72	50004204	DOOR HANDLE CURVED -128mm	2
73	50004255	CASTER 3IN	2
74	50004256	CASTER 3IN W/BRAKE	2
75	91D0155	HARDWARE BAG CASTERS	1
77	50004650	TANK PULL OUT ASSEMBLY - LP ONLY	1
N/S	30005743	CART BACK PANEL - BLACK	1
N/S	20300389	CART SIDE PANEL RIGHT	1
N/S	20300390	CART SIDE PANEL LEFT	1
N/S	20300399K	CORNER POST SS	4
N/S	30005820	BOTTOM PANEL BLACK	1
N/S	30006061	VC GRILL COVER - BAGGED	1
N/S	30005801	USER MANUAL	1

N/S	30005803	ASSEMBLY MANUAL	1
N/S	30005804	PARTS LIST	1
N/S	20304535	CONVERSION KIT - LP TO NG	0
N/S	20304536	CONVERSION KIT - NG TO LP	0

Woodmans Parts Plus