

VCS523SSBI

Reference #	Part #	Description	Quantity Required
1	50003462	ROTISSERIE BURNER ASSEMBLY	1
2	50003472	ROTISSERIE ELECTRODE	
3	50004145	TUBE AND ORFICE ASSEMBLY - LP	
3a	50004146	TUBE AND ORFICE ASSEMBLY - NG	
4	50003473	ELECTRODE ROTISSERIE WIRE	
5	94D0134	ROTISSERIE KIT - w/o spit rod	
6	20305074	ROTISSERIE MOTOR BRACKET	
7	50000399	SUPPORT ROTISSERIE SPIT ROD	
8	91D0131	ROTISSERIE MOTOR ONLY	
9	20300417	SPIT ROD 38IN	
10	30005843	FRONT LID ASSEMBLY - SS	
11	30005342	WARMING RACK	
12	30005396K	REAR LID ASSEMBLY	
13	91D0132	BURNER MAIN ANGLE ASSEMBLY - INCL. ELECTRODE AND WIRE	
15	91D0108	ELECTRODE WIRE	
16	91D0107	ELECTRODE ONLY - MAIN	
17	50000892	BURNER GASKET	
18	50001300	FLASH TUBE	
19	30005707	VC LOGO	
20	20300394	TEMPERATURE GAUGE	
21	50005393	CURVED HANDLE GRIP SET	
22	50000365	LID BUMPER SET (6)	
23	50000355	HARDWARE LID SET	
24	30005505	CONSOLE w/RIVNUT ASSEMBLY	
25	50004324	WIRE HARNESS	
26	50003110	BATTERY CASE	
27	50002788	IGNITOR PUSHBUTTON	
28	50002533	IGNITOR PLATE	
29	50004221	IGNITOR MODULE ASSEMBLY	
30	50003002	BEZEL	
32	50003984	KNOB	
34	20302818	VALVE MANIFOLD ASSEMBLY - LP	
34a	20302819	VALVE MANIFOLD ASSEMBLY - NG	
35	50000672	FLEXIBLE CONNECTOR 28IN.	
36	91D0111	HOSE REGULATOR - LP	
37	91D0112	CONNECTOR HOSE - NG	
38	50004781K	SUPPORT GRILL / GREASE TRAY	
39	50001950	GREASE TRAY	
40	50004799	REAR COVER	
41	50004814	GREASE TRAY FRONT ASSEMBLY	
42	50004733	FASCIA BRACKET RIGHT	

43	50004734	FASCIA BRACKET LEFT
44	20304959	HEAT PLATE
45	30005363	COOK GRATE
46	50004204	DRAWER HANDLE CURVED -128mm
47	50004855	HARDWARE BAG
48	50002384	12 FOOT HOSE - NG
49	20300395	BEZEL FOR TEMPERATURE GAUGE
N/S	20304636	CONVERSION KIT - LP TO NG
N/S	20304640	CONVERSION KIT - NG TO LP
N/S	30005801	USER MANUAL
N/S	20304966	ASSEMBLY MANUAL
N/S	20304963	PARTS LIST
N/S	VCS500 BIC	GRILL COVER

Woodmans Parts Plus