

VCS6006

Reference #	Part #	Description	Quantity Required
1	50003846	CABINET ASSEMBLY - LEFT	1
2	50003847	HOSE NATURAL GAS	1
4A	50003654	DOOR ASSEMBLY - RIGHT	1
4B	50003655	DOOR ASSEMBLY - LEFT	1
5	50003604	DRAWER ASSEMBLY	1
6	50000313	DOOR HANDLE	3
7	50003719	SHELF, LEFT	1
8	50003720	SHELF, RIGHT	1
9	50003723	SIDE BURNER LID	1
10	50001035	SIDE BURNER GRATE	2
11	50001044	BURNER (FOR THE SIDE BURNER)	2
12	50001092	SIDE BURNER HOSE	1
13A	50002828	VALVE, MANIFOLD ASSEMBLY SIDEBURNER (LP)	1
13B	50002829	VALVE, MANIFOLD ASSEMBLY SIDEBURNER (NG)	1
14A	50002233	TUBE & ORIFICE SIDE BURNER DUAL (LP)	1
14B	50002307	TUBE & ORIFICE SIDE BURNER DUAL (NG)	1
15A	50002238	TUBE & ORIFICE SIDE BURNER DUAL (LP)	1
15B	20002277	TUBE & ORIFICE S/B (LONG) - NATURAL	1
16	50003258	SIDE BURNER ELECTRODE SHORT (8)	1
17	50003259	SIDE BURNER ELECTRODE LONG (16)	1
18	50000816	IGNITOR KIT- SIDE BURNER	1
19	50003648	KNOB BEZEL	2
20	50003003	CONTROL KNOB	2
21	50003675	BASE ASSEMBLY	1
22	50003133	BURNER TUBE WITH LONG ELECTRODE	4
23	91D0108	ELECTRODE WIRE MAIN LONG - NEED 91D0107 FOR ELECTRODE	4
23A	91D0107	ELECTRODE ONLY - MAIN	4
24	50003100	BURNER TUBE WITH SHORT ELECTRODE	2
25	50000431	ELECTRODE MAIN SHORT	2
26	50001300B	FLASH TUBE	3
27	50000879	FLASH TUBE	1
28	50000892	BURNER GASKET	6
32	50001619	IGNITOR MODULE- PUSHBUTTON NOT INCL. (ON OLDER VC GRILLS SOME MODIFICATION MAY BE REQUIRED TO MOUNT)	1
33	50002788	IGNITOR PUSH BUTTON	1
34	50003462	ROTISSERIE BURNER ASSEMBLY	1
35A	50003238	TUBE & ORIFICE ASSEMBLY (LP)	1
35B	50003239	TUBE & ORIFICE ASSEMBLY (NG)	1
36	50003472	ROTISSERIE ELECTRODE - INCLUDED IN PART 50003462.	1
37	50003473	ROTISSERIE ELECTRODE WIRE	1
38	50003592	CONSOLE REINFORCEMENT	1
39	50003593	CONSOLE	1

41	50001845	GREASE CUP	1
42A	50002830	VALVE, MANIFOLD ASSEMBLY (LP)	1
42B	50002831	VALVE, MANIFOLD ASSEMBLY (NG)	1
43	50002310	REGULATOR ASSEMBLY (LP)	1
44	50002422	HOSE NATURAL GAS	1
45	50002384	12 HOSE NATURAL GAS	1
46	50000972	BOLT 6 (32 X 1/4 SS, ATTACHES BEZELS TO CONSOLE)	14
47	50003002	BEZEL ASSEMBLY (BACKLIT)	7
48	50003003	KNOB ASSEMBLY (BACKLIT)	7
49	50003508	WIRING HARNESS	1
50	50003518	REAR LID ASSEMBLY (REQUIRES PART 50000355)	1
51	50000355	PIVOT PIN & BOLT SET - SEND WITH LID ASSEMBLY	1
52	50003644	FRONT LID ASSEMBLY (REQUIRES PART 50000355)	1
53	50001643	TEMPERATURE GAUGE - SUBS to 20300395 & 20300394	1
54	50000642	GRIP HANDLE SET	1
55	50000365	LID BUMPERS (SET OF 6)	1
57	50003116	ROTISSERIE KIT (SPIT ROD NOT INCLUDED)	1
59	50000161	ROTISSERIE MOTOR	1
60	50003669	SHELF LIGHT ASSEMBLY (PERISCOPE)	1
61	50003110	BATTERY CASE (SHELF LIGHT)	1
62	50003390	HARDWARE BAG	1
63	50003400	CASTER 3 X 1 1/4	4
64	50001911	BOLT 1/4 - 20 X 5/8 SS	24
65	50002110	BOLT 1/4 - 20 X 5/8 BLACK	12
67	50000315	SCREW 8 - 18 X 1/2 SS	6
68	50002433	BOLT 6 - 32 X 3/8 SS	6
69	50001026	SCREW 8 - 18 X 3/8 ZINC	7
70	50001055	SCREW 8 - 18 X 1/2 BLACK	20
N/S	50003767	KIT - SHELF, LEFT	1
N/S	50003768	KIT - SHELF, RIGHT (LP)	1
N/S	50003769	KIT - SHELF, RIGHT (NG)	1
N/S	50003630	TANK PULL-OUT KIT (LP MODELS ONLY)	1
N/S	50000156	COOK GRATE - SINGLE APPROX 16 X 9	5
N/S	VCDC6SB	DELUXE BBQ COVER	1
N/S	50002241	GRIDDLE PLATE	1
N/S	50000777	HEAT PLATE - SS	6
N/S	50003243	INTERNAL SHELF	1
N/S	50003678	GREASE PAN	1
N/S	50003313	WARMING RACK (ENAMEL)	1
N/S	50000962	ROTISSERIE SPIT ROD 38	1
N/S	10008764	SIZZLING BARBECUE COOKBOOK	1
N/S	50002198	CABINET FORM BLOCK - THERMOPLASTIC	2