

# COMFORT FLAME See-Thru Vent-Free Firebox

MODELS: FBST

	Part Number	Description
1	**	Firebox Assembly
2	**	Firebox Bottom
3	**	Firebox Top
4	23982	Top Spacer
5	26731	Deflector Hood (2 Required)
6	26740	Nailing Flange
7-1	23519	Side Refractory (2 Required)
7-2	26540	Bottom Refractory (2 Required)
8	24007	Side Refractory Retainer
9	12125	Screen (4 Required)
10	26752	Extruded Louver Top (2 Required)
11	26733	Lower Door Panel (2 Required)
12	14200	Receptacle
13	21171	Access Hole Cover
14	11192	Shoulder Screws
15	11164	Screw, #10 x 1/2, zinc PH
16	11165	Screw, #10 x 5/8, zinc PH
<b>PARTS AVAILABLE - NOT SHOWN</b>		
	24029	Screen Rod (4 Required)