

VM406

REF #	Part #	Part Description	QTY
1	50003726	BASE ASSY	1
2	50000892	BURNER GASKET	3
23	50000877	HEAT PLATE (ENAMEL)	3
24	50001301	GREASE PAN	1
25	50001845	GREASE CUP	1
26	50001319	GREASE CUP HOLDER	1
27	50003612B	SHELF - LEFT / RIGHT	2
28	50002534	CASTER INSERT	4
29	50000090	CASTER - LOCKING	2
30	50002657	CASTER - NON LOCKING	2
31	50003609	LEG ASSY - LEFT	2
32	50003610	LEG ASSY - RIGHT	2
33	50003633	LEG BRACE	2
34A	50003708	BOTTOM PANEL REPLACEMENT - LP	1
34B	50003710	BOTTOM PANEL REPLACEMENT - NG	1
35	50003725	MAIN HARDWARE BAG	1
48	50000255	PUSH NUT FOR LOGO ON FRONT LID	3
49	50003727	FRONT PANEL VM400	1
NS	50001382	PUSH PINS	0

VM406

50	50003670	WARMING RACK (ENAMEL)	1
NS	50003432	CONSOLE REPAIR KIT	1
N/A	VC303-3496	BBQ COVER - SALE ITEM	1
N/A	VC703-1244	26 , ROTISSERIE KIT - SALE ITEM	1
N/A	50003734	KIT - MAIN PARTS (LP)	1
N/A	50003735	KIT - MAIN PARTS (NAT. GAS)	1
N/A	50003728	KIT - SHELVES	1
N/A	50003611	KIT - LEGS	2
3	50003133	BURNER ASSY - WITH LONG ELECTRODE	2
	50003100	BURNER ASSY - WITH SHORT ELECTRODE	1
N/A	50003457	BURNER REPAIR KIT.	3
4	50001300B	FLASH TUBE	1
5	50003622B	CONSOLE HEAT SHIELD	1
6A	50002516	VALVE ASSY LP	1
6B*	50002515	VALVE ASSY NG	1
7A	50003647	HOSE REGULATOR - LP	1
7B*	50000198	HOSE REGULATOR - NG	1
8	50003624	CONSOLE PRINTED VM400	1
9	50000816	IGNITOR KIT (Push button IS included)	1
10	50003623B	CONSOLE REINFORCEMENT	1
11	50002212	GROUND WIRE	1
12	50003512	REAR LID ASSY - Also send p/n 50000355.	1

VM406

13	50002606	FRONT LID ASSY - Also send p/n 50000355.	1
14	50001643	TEMPERATURE GAUGE	1
15	50002532	LOGO - Also send push nut p/n 50000255.	1
16	50000355	PIVOT PIN & BOLT SET - Send with lid assy.	1
17	50000365	LID BUMPERS (COMES IN A SET OF 6)	1
18	50000431	ELECTRODE - MAIN - SHORT	1
19	50000523	ELECTRODE - MAIN - LONG	2
20	50003648	BEZEL FOR CONTROL KNOBS	3
21	50001328	CONTROL KNOBS	3
22	50001314	COOKING GRIDS (SET OF 2)	1

Woodmanspartsplus