

VM450

REF #	Part #	Part Description	QTY
1	50002799	BASE ASSY	1
2	50001844B	GREASE PAN SUPPORT	1
19	50001643	TEMPERATURE GAUGE	1
20	50000355	PIVOT PIN & BOLT SET Send with lid assembly.	1
21	50003320	DOOR ASSY VM450	1
22	50003322B	FASCIA DOOR VM450	1
23	50000802	WARMING RACK (ENAMEL)	1
24	50003189	CONDIMENT SUPPORT ASSY - LEFT	1
25	50003013	CONDIMENT SUPPORT ASSY - RIGHT	1
26	50001845	GREASE CUP	1
27	50003011	UTENSIL HOOK (SET OF 3)	1
28	50000090	CASTER (POP IN)	4
29	50003330	SIDE BURNER SHELF ASSY - RIGHT	1
30	50003059	SIDE BURNER LID ASSY	1
	50003314	SHELF SUPPORT ASSY (W. BRACKETS) -RT	1
31	50003332	SHELF ASSY - LEFT	1
	50003315	SHELF SUPPORT ASSY (W. BRACKETS) -LT	1
32	50001226	COOKING GRIDS (SET OF 3)	1
33	50000877	HEAT PLATE (ENAMEL)	4

VM450

34	50003043M	SIDE BURNER ASSY (COMPLETE)	1
35	50003050	SIDE BURNER - GRATE	1
36	50001044	SIDE BURNER - BURNER ASSY	1
37	50000111	SIDE BURNER - ROTARY IGNITOR - 2 TERM	1
38	50000115	SIDE BURNER - ELECTRODE	1
39	50000113	SIDE BURNER - VALVE KNOB	1
40	50000070	SIDE BURNER - IGNITOR KNOB	1
41	50002888	CYLINDER RETAINER	1
42	50000365	LID BUMPERS (SET OF 6)	1
43	50003198	STABILIZER BRACKET ASSY	1
44a	50003208	HANDLE DOOR ROUND	1
44	50000313	DOOR HANDLE DELUXE	1
N/A	50003056	HARDWARE KIT	1
N/A	50002033	POP IN MAGNETS - DOORS	2
N/A	50003308B	CONDIMENT TRAY - LH	1
N/A	50003282B	CONDIMENT TRAY - RH	1
N/A	50002828B	CABINET (ROUND) - LEFT S/S	1
N/A	50002829B	CABINET (ROUND) - RIGHT S/S	1
N/A	50002832	BOTTOM PANEL BLK	1
N/A	50002889	BACK PANEL	1
N/A	50002198	CABINET FORM/NUT ASSY	2
N/A	50003432	CONSOLE REPAIR KIT	1

VM450

N/A	VC303-3576	BBQ COVER	1
N/A	VC703-1284	29 ROTISSERIE KIT	1
N/A	VCGP1A	GRIDDLE - replaces one cooking grid	1
3	50002155	GREASE PAN ASSY	1
4	50000879B	FLASH TUBE	1
5	50000892	BURNER GASKET	4
6	50000431	ELECTRODE - LONG	2
N/A	50000523	ELECTRODE - SHORT	2
7	50003100	BURNER TUBE with SHORT ELECTRODE	2
N/A	50003133	BURNER TUBE with LONG ELECTRODE	2
NS	50003457	BURNER REPAIR KIT	4
8a	50002822	VALVE ASSY - LP	1
8b	50002823	VALVE ASSY - NG	1
9a	50002900	HOSE & REGULATOR - LP	1
N/A		FOR THE MAIN & SIDE BURNER	1
9b	50002901	HOSE & REGULATOR - NG	1
N/A		FOR THE MAIN & SIDE BURNER	1
10	50003323	CONSOLE VM450 (PRINTED)	1
11	50002825B	CONSOLE REINFORCEMENT	1
N/A	50003319B	CONSOLE REINFORCEMENT LIP	1
12	50002533	IGNITOR PLATE	1
13	50000816	IGNITOR KIT (Push button included)	1

VM450

14	50002551	BEZEL	4
15	50001328	KNOB	4
16	50003514	LID ASSY - REAR. Also send p/n 50000355.	1
17	50002834	LID ASSY - FRONT. Also send p/n 50000355.	1
18	50002532	LOGO	1

Woodmanspartsplus