

VM606

REF #	Part #	Part Description	QTY
1	50003846	CABINET ASSY - LEFT	1
2	50003847	CABINET ASSY - RIGHT	1
26A	50000819	TUBE & ORIFICE ASSY - LP	1
26B*	50000818	TUBE & ORIFICE ASSY - NG	1
27	50003472	ROTISSERIE ELECTRODE	1
28	50003473	ROTISSERIE ELECTRODE WIRE	1
29	50003589B	CONSOLE REINFORCEMENT	1
30	50003590	CONSOLE PRINTED VM600	1
31	50002157	GREASE PAN	1
32	50001845	GREASE CUP	1
33A	50002826	VALVE ASSY - LP	1
33B	50002827	VALVE ASSY - NG	1
34	50003815	HOSE REGULATOR - LP	1
35	50000920	HOSE NATURAL GAS	1
36	50000198	12 - FOOT NATURAL GAS HOSE	1
37	50000972	BOLT #6 (32 X 1/4 SS, Attaches bezels to console)	12
38	50003002	BEZEL ASSY - BACKLIT	5
39	50003003	KNOB ASSY - BACKLIT	5
40	50003507	WIRING HARNESS	1

VM606

41	50003516	REAR LID ASSY - Also send p/n 50000355.	1
42	50000355	PIVOT PIN & BOLT SET - Send with lid assy.	1
43	50003018	FRONT LID ASSY - Also send p/n 50000355.	1
44	50001643	TEMPERATURE GAUGE	1
45	50000365	LID BUMPERS (SET OF 6)	1
46	50000889	WARMING RACK (ENAMEL)	1
47	50003562	SIDE BURNER ASSY	1
48	50003050	GRATE - SIDE BURNER	1
49	50001044	BURNER - SIDE BURNER	1
50A	50001046	VALVE LP - SIDE BURNER	1
50B	50001045	VALVE NG - SIDE BURNER	1
51	50000115	ELECTRODE - SIDE BURNER	1
52	50000113	CONTROL KNOB - SIDE BURNER	1
53	50000070	IGNITOR KNOB - SIDE BURNER	1
54	50000111	IGNITOR (ROTARY, 2 TERM) - SIDE BURNER	1
55	50003116	ROTISSERIE KIT - NO spit rod	1
56	50000962	SPIT ROD - Is NOT Rotisserie Kit	1
57	50000161	ROTISSERIE MOTOR	1
58	50003669	SHELF LIGHT ASSY (PERISCOPE)	1
59	50003681	MAIN HARDWARE BAG	1
60	50000090	CASTER	4
N/A	50002033	POP IN MAGNETS (DOORS)	2

VM606

N/A	50003286	BATTERY SHROUD ASSY	1
N/A	50003110	BACKLIT KNOB BATTERY CASE	1
N/A	50002198	CABINET FORM/NUT ASSY	2
N/A	50003543	BOTTOM PANEL	1
N/A	50003434	CONSOLE REPAIR KIT	1
N/A	VC303-3666	BBQ COVER	1
N/A	VCGP1A	GRIDDLE (replaces one cooking grid)	1
N/A	50003753	KIT - MAIN PARTS	1
N/A	50003562	KIT - SIDE BURNER ASSY	1
N/A	50003669	KIT - SHELF LIGHT ASSY	1
N/A	50003749	KIT - CONDIMENT TRAY	1
3	50003661	DOOR ASSEMBLY - LEFT	1
4	50003660	DOOR ASSEMBLY - RIGHT	1
5	50003601	DRAWER ASSEMBLY	1
6	50000313	DOOR HANDLE	3
7	50001418	SHELF SUPPORT BLACK - Left rear & right front	1
8	50001419	SHELF SUPPORT BLACK - Right rear & left front	1
9	50003598	SHELF, LEFT	1
10	50003581	SHELF, RIGHT	1
11	50003558B	LID ASSY - SIDE BURNER	1
12	50003679	CONDIMENT TRAY - RIGHT	1
13	50003680	CONDIMENT TRAY - LEFT	1

VM606

14	50003730	BASE ASSY	1
15	50003133	BURNER ASSY W. LONG ELECTRODE	3
16	50000523	ELECTRODE - MAIN - LONG	3
17	50003100	BURNER ASSY W. SHORT ELECTRODE	2
18	50000431	ELECTRODE - MAIN - SHORT	2
N/A	50003457	BURNER REPAIR KIT	5
19	50001300B	FLASH TUBE	2
20	50000892	BURNER GASKET	5
21	50000777	HEAT PLATE - S/S	5
22	50001227	COOKING GRIDS (SET OF 4)	1
23	50001619	IGNITOR MODULE - NO push button.	1
24	50001011	IGNITOR PUSH BUTTON	1
25	50003462	ROTISSERIE BURNER ASSY	1