

Valor 479 Homeflame

No.	Description 479 Parts	Part No.	Key No.	Description 479 Parts	Part No.
1	Firebox Unit	549309	31	Seal-Burner Inlet Block	551109
2	Air Duct Box	549199	32	Main Burner	551129 553779(P)
3	Seal-Air Duct Box-Sides	549179	33	Decorative Flame Burner	551139 554329(P)
4	Seal-Air Duct Box-Top & Bottom	549189	34	Pilot & Electrode Unit	506649 506869(P)
5	Seal-Vent Port	549329	35	Piezo Ignition Lead	551169
6	Seal-Firebox Air Inlet	549339	36	Seal-Pilot Unit	551159
7	Back Panel Unit	551009	37	Thermocouple	551179
8	Back Panel Spacer	550799	38	Thermocouple Interrupter	554309
9	Rear Heat Shield	549229	39	Pressure Relief Cover	510509
10	Rear Cooler Plate	551399	40	Sealing Washer	510529
11	Sealing Ring	549799	41	Spring Loaded Bushing	510519
12	Vent Collar	549209	42	Control Valve	548509
13	Vent Collar Support Bracket	506619	43	Locknut 15mm	502739
14	Heat Shield - Left Side	551469	44	Control Shaft Connector	553869
15	Outer Frame Top Location Bracket	549239	45	Switch Clamping Plate	553819
16	Control Valve Bracket	551019	46	Control Shaft	553809
17	Regulator Bracket	551049	47	Ignition Safety Switch	553839
18	Outer Frame Bottom Fixing Bracket- Right Side	550809	48	Gas Pressure Regulator (Suitable for all serial nos) Gas Pressure Regulator (For Serial Nos including letter G upwards)	551219 503049(P) 508199 508209(P)
19	Outer Frame Bottom Fixing Bracket-Left Side	550819	49	Screw #6x 1/4" Tapite 32 t.p.i.	548609
20	Ignition Generator Shield Unit	551409	50	Elbow-Regulator Connector	548749
21	Piezo Electric Ignition Generator	554909	51	Pressure Test Fitting Unit	548739
22	Generator Shield Access Cover	549299	52	Pipe Unit-Pressure Test Unit to Valve	551229
23	Log Front Support Bar	555159	53	Supply Inlet Pipe	551449
24	Burner Inlet Block & Injector Unit (Includes Keys 52 through 54)	554279 506859(P)	54	Supply Inlet Connector	551459
25	Burner Inlet Block	551069	55	Pipe Kit (Pipe, Nut, & Ferrule)-Pilot to Valve	551229
26	Gas Injector-Decorative Flame Burner	551089 554387(P)	56	Nut for pipe	551249
27	Gas Injector-Main Burner Gas Injector-Main Burner(outer)	553759(P) 554289	57	Ferrule for pipe	551259
27A	Gas Injector-Main Burner (centre)	554299	58	Pipe Unit-Valve to Main Burner Centre Inlet	551269
28	Burner Box Unit	551099	59	Pipe Unit-Valve to Flame Burner Centre Inlet	551279
29	Seal-Burner Box Sides	549549			
30	Seal-Burner Box Bottom	549559			

Woodman's Parts Plus
www.woodmanspartsplus.com

Key No.	Description 479 Parts	Part No.	Price
60	Pipe Unit-Valve to Outer Burners Inlet	551289	6.00
61	Window Unit	549729	84.30
62	Log Support Base	551299	26.50
63	Wing Nut 5mm Bright	533249	
64	Window Surround Trim Unit	549119	20.00
65	Control Knob	548519	2.00
66	Log #1	557649	12.00
67	Log #2	557659	12.00
68	Log #3	557669	12.00
69	Log #4	557679	12.00
70	Log #5	557689	12.00
71	Left Side Cheek	549619	6.25
72	Right Side Cheek	549629	6.25
73	Outer Rear Frame (Black)	551039	37.00
73	Outer Rear Frame (White)	519599	37.00
74	Control Position Indicator Pin	530939	1.00
75	Hood Unit (Black)	549929	54.00
75	Hood Unit (White)	507629	47.00
76	Hood Top Heatshield	549059	16.00
77	Spacer-Hood Top Heatshield	549069	1.00

Key No.	Description 479 Parts	Part No.	Price
78	Rear Frame Locator-Short	549809	1.00
79	Rear Frame Locator-Long	549819	1.00
80	Left Side Panel-Black	547499	11.00
80	Left Side Panel-White	507649	35.00
81	Right Side Panel-Black	547489	11.00
81	Right Side Panel-White	507639	35.00
82	Upper Front Heatshield	547509	12.00
83	Hearth Fender & Apron Unit-Black	551309	44.50
83	Hearth Fender & Apron Unit-White	507659	57.00
84	Brass Andiron	549029	25.00
85	Knurled Head Screw	549109	1.00
86	Vent Unit	554319	39.00
87	Sealing Ring-Vent to Wall Plate	551329	5.00
88	Wall Plate	554329	5.00
89	Outer Vent Shield Tube	554339	9.00
90	Sealing Ring	549799	5.00
91	Wall Heatshield (incl. keys 92-94)	557699	67.00
92	Wall Heatshield Plate	508219	4.00
93	Heatshield Plate Spacer	508229	1.00
94	Sealing Ring	551329	5.00