

Vogelzang BX22EL Parts List

<b>Ref. No.</b>	<b>Part No.</b>	<b>Description</b>	<b>Qty.</b>
01	L22-01	Leg.....	3
01b	L22-01b	Leg (with mounting holes) .....	1
02	L22-02	Bottom .....	1
03	L22-03	Side .....	2
04	L22-04	Back.....	1
05	L22-05	Slide Draft Damper .....	1
06	L22-06	Front .....	1
07	L22-07	Feed Door.....	1
08	L22-08	Top.....	1
09			
10	L22-10	Hearth.....	11
11	L22-11	Door Pin.....	2
12	L22-12A	Damper Collar Assembly .....	1
13			
14	L22-14A	Heat Shield Assembly .....	1
15	L22-15	Heat Shield Hanger .....	4
16	L22-16	Heat Shield Separator .....	4
17	L22-17A	Separable Handle Assembly .....	1
18	L22-18	Handle Holder.....	1
19	L22-HP	Hardware Pack, Complete .....	1
29	M6x1	Hex Nut.....	4
31	M6x1 x 8	Pan Hd. Mach. Screw .....	2
32	M6	Lock Washer .....	4
35	M6x1 x 45	Leg Bolt .....	4
36			