

CABINET ASSEMBLY - THERMOSTAT

Item No.	Description	Part Number
1	Cabinet Top Assembly.....	510368
2	Cabinet Back Assembly.....	X510370
3	Cabinet, Right Side.....	X510373
4	Cabinet Door.....	X510372
5	Knob, Cabinet Door.....	510127
6	Door Strike.....	510366
7	Bottom Front Panel Assembly.....	X510374
8	Cabinet, Left Side.....	X510376
9	Front Frame Assembly.....	X510367
10	Knob, Thermostat.....	510180
11	Plate, Thermostat Trim.....	510325
12	Cotter Key.....	121267
13	Washer, Flat.....	120479
14	Spring, Thermostat.....	510182
15	Disc, Friction (Inside).....	510222
16	Housing, Thermostat.....	510187
17	Disc, Friction (Outside).....	510185
18	Thermostat Assembly (Bimetal).....	X510530
19	Adjustment Nut.....	121382
20	Adjustment Screw.....	121405
21	Rod, Thermostat.....	510207

Woodmanspartsplus.com

Model W6-78 C

Woodmaster Automatic Heater

Item		Part
No.	Description	Number
22	Firebox Assembly.....	X510545
23	Gasket, Flue Collar.....	.510335
24	Flue Collar.....	.510166
25	Plate, Secondary Air Adjustment.....	.510164
26	Pin, Hinge (Cast Door).....	.510197
27	Door, Load.....	.510167
*27A	Gasket, Load Door.....	.070394
28	Latch, Door.....	.510169
29	Handle, Door.....	.510168
30	Eyelet Screw.....	.510578
31	Pull Handle (Wood).....	.510577
32	Shield, Handle.....	.510654
33	"Z" Bracket Assembly, Top.....	.510221
34	Clamp, Smoke Baffle.....	.510583
35	Firebrick.....	.510161
36	Smoke Baffle.....	.510258
37	"Z" Bracket Assembly, Bottom....	.510157
38	Heat Liner, Right Side.....	.510155
39	Ash Pan.....	.510428
41	Grate.....	.510160
42	Heat Liner, Left Side.....	.510151
43	False Bottom.....	.510145
44	Door, Ash.....	.510170
*44A	Gasket, Ash Door.....	.070393
45	Draft Door Assembly.....	X510418
46	Pin, Draft Door.....	.510165
47	Manifold, Draft.....	.510162
48	Heat Shield, Floor.....	.510657