

Key No.	Description	Part Number
1	Cabinet Back	510274
2	Stop, Main Top (Steel Cable)	A150040
3	Firebox Assembly Complete	X510142
4	Front Frame Assembly	510131
5	Plate, Thermostat (Trim)	510181
6	Cabinet, Left Side	510128
7	Bottom Front Panel Assembly	510138
8	Knob, Thermostat	510180
9	Fire Brick	510161
10	"Z" Bracket Assembly, Top	510221
11	Manifold, Draft	510162
12	Draft Door Assembly	510209
13	Heat Liner, Left Side	510151
15	Smoke Baffle	510258
16	Ash Pan	510173
17	Heat Liner, Right Side	510155
18	Grate	510160
19	Latch, Door	510169
20	Door, Ash	510170
*20A	Gasket, Ash Door	070393

Key No.	Description	Part Number
21	Handle, Door	510168
21A	Lock Nut 1/4-20	510225
22	Door Strike	510195
23	Knob, Cabinet Door	510127
24	Door, Cabinet Assembly	510121
25	Door, Loading	510167
*25A	Gasket, Loading Door	070394
26	"Z" Bracket Assembly, Bottom	510157
27	Cabinet Top Assembly	510118
28	Flue Collar	510166
29	Bracket, Cabinet Back	510193
30	Spring, Thermostat	510182
31	Rod, Thermostat	510207
32	Adjustment Screw #8-32	— —
33	Adjustment Nut	510208
34	Thermostat Assembly (Bimetal)	510178
35	Disc, Friction (Inside)	510222
35A	Disc, Friction (Outside)	510185
36	Housing, Thermostat	510187
37	Washer, Flat	————
38	Cotter Key	————