

WESO Renaissance Parts List

KEY FOR EXPLODED DRAWING

- |                           |   |  |
|---------------------------|---|--|
| 1. Base                   | 16. Air Regulator Slider                | 31. Burning Chamber, Right, Inside Plate |
| 2. Bottom Plate           | 17. Recessed Screws                     | 32. Stainless Steel Air Channel          |
| 3. Flat Head Screws       | 18. Screw Bolt                          | 33. Flat Head Screws                     |
| 4. Back Plate             | 19. Brass Knob for Slider               | 34. Graphited Gasket Cord                |
| 5. Side Plate, Left       | 20. Graphited Gasket Cord               | 35. Air Guide                            |
| 6. Side Plate, Right      | 21. Upper Hinge, Long                   | 36. Damper*                              |
| 7. Front Plate            | 22. Recessed Screws                     | 37. Damper Frame                         |
| 8. Top Plate              | 23. Lower Hinge, Left and Right, Long   | 38. Damper Rod                           |
| 9. Flat Head Screws       | 24. Grate Support Plate                 | 39. Flat Head Screws                     |
| 10. Washers               | 25. Grate, Left                         | 40. Brass Knob for Closing Door          |
| 11. Nut                   | 26. Grate, Right                        | 41. Screw Bolt                           |
| 12. Cooking Plate         | 27. Shaking Rod                         | 42. Anvil Plate                          |
| 13. Recessed Screws       | 28. Cotter Pin                          | 43. Bent Steel Rod                       |
| 14. Graphited Gasket Cord | 29. Washers                             | 44. Recessed Screws                      |
| 15. Air Channel           | 30. Burning Chamber, Left, Inside Plate | 45. Flue Collar                          |

\*To be opened while servicing stove only.

- |  |                                     |                                 |
|--|-------------------------------------|---------------------------------|
| 46. Graphited Gasket Cord                | 61. Half Corner Tile                | 76. Front Door, Left            |
| 47. Fire Door                            | 62. Tension Rod                     | 77. Hinge for Front Door, Short |
| 48. Glass Holding Frame                  | 63. Enamalled Facia, Left           | 78. Brass Clips                 |
| 49. Pin                                  | 64. Flat Head Screw, Black          | 79. WESO Logo                   |
| 50. Door Gasket                          | 65. Tile Holding Plate, Upper Right | 80. Top Grille                  |
| 51. Graphited Gasket Cord(2)             | 66. Tile Holding Plate, Lower Right | 81. Straight Pins               |
| 52. Closing Latch(including rod and nut) | 67. Enamalled Facia, Right          | 82. Small Double Heat Shield    |
| 53. Recessed Screws                      | 68. Carrying Frame for Ledge Tiles  | 83. Ash Pan and Cover           |
| 54. Robax Schott-Glass                   | 69. Ledge Tile, front Left          | 84. Large Double Heat Sheild    |
| 55. Ash Door                             | 70. Ledge Tile, Front Right         | 85. Flat Head Screws            |
| 56. Pin                                  | 71. Ledge Tile, Rear Left           | 86. Sheet Metal Screws          |
| 57. Graphited Gasket Cord                | 72. Ledge Tile, Rear Right          | 87. Latch Spring                |
| 58. Tile Holding Plate, Upper Left       | 73. Ledge Tile, Center Front        | 88. Flat Head Screws            |
| 59. Tile Holding Plate, Lower Left       | 74. Flat Head Screws                | 89. Screw Pin                   |
| 60. Full Corner Tile                     | 75. Front Door, Left                |                                 |