

Monessen Windsor Fireplace Insert

Item No.	Description	Qty.	Part No.
1.	Door Casting - Black	1	S12071
2.	Glass and Gasket	1	S31141
3.	1/8" (3 mm) Glass Gasket	4.6'	S15001
4.	5/8" (16 mm) Door Gasket	5.2'	S15011
5.	Pawl Assembly	1	30002362
6.	Handle - Black, Wood	1	1600664
7.	Insert Lifter Handle - Nickel	1	1600650
8.	Screw - 1/4-20 x 3	1	1201310
9.	Handle Assembly	1	5004245
10.	Lock Nut	1	1203290
11.	Glass Clips	7	S37034
12.	Screw #10 x 1/2	7	S11086
13.	Hinge Pin	2	S11005
14.	3/8 Retaining Ring	2	S11090
15.	Baffle Assembly	1	S41467
16.	Secondary Air Tube	3	S32711
17.	Cotter Pin	3	S11421
18.	Firebrick 4 ⁷ / ₁₆ " (113 mm) x 9" (229 mm) x 1 ¹ / ₄ " (32 mm)	9	S16040
19.	Firebrick 4 ⁷ / ₁₆ " (113 mm) x 7 ¹ / ₄ " (184 mm) x 1 ¹ / ₄ " (32 mm)	2	S16043
20.	Firebrick 4 ⁷ / ₁₆ " (113 mm) x 4 ¹ / ₂ " (114 mm) x 1 ¹ / ₄ " (32 mm)	1	S16046
21.	Firebrick 2 ¹ / ₄ " (57 mm) x 8" (203 mm) x 1 ¹ / ₄ " (32 mm)	1	S16271
22.	Firebrick - Angled	2	S16013
23.	Firebrick 4 ⁷ / ₁₆ " (113 mm) x 8" (203 mm) x 1 ¹ / ₄ " (32 mm)	4	S16138
24.	Faceplate - Top	1	S38050
25.	Faceplate - Side	2	S38051
26.	Trim - Top Right	1	90000072
27.	Trim - Top Left	1	90000071
28.	Trim - Side Right	1	90000078
29.	Trim - Side Left	1	90000075
30.	Corner - 90°	2	S11092
31.	#8 Screw	6	50960
32.	Spring	2	S11403
33.	Articulated Angle	1	S11127
34.	Back plate, Trim Corner	2	30004606
35.	Back plate, Articulated Angle	2	30004607