

Cookstove Parts List

Part #	Description	Part #	Description	Part #	Description
1005	Firebox base	1359	Screw & nut for lift handle	4222	Firebrick - right(SweetHeart)
1010	Short leg nickel plated	1361	Lift handle/washer complete	4223	Firebrick - front(SweetHeart)
1015	Firebox wrap around	1376	Key plate polished (Oval only)	4225	Damper slide(SweetHeart)
1045	Cast fire door	1380	9 1/2" solid lid	4228	Damper arm(SweetHeart)
1095	Long stove leg	1391	6" lid	4271	Summer Grate support
1101	Complete oven door assembly	1415	Lid lifter	4277	Towel rack(SweetHeart #2)
1107	Oven door frame	1420	Stove poker	4286	Front surface band
1110	Oven door handle stanchion	1425	Ash scraper	4289	Wrap around band(SweetHeart #2)
1115	Woodenoven door handle	1440	Tool rack	4297	Reservoir band(SweetHeart #3)
1120	Outer oven door panel	1460	6" Dia Oval flue weldment	4300	Firedoor panel
1127	Interior Oven Thermometer	1521	Splash back	4305	Firedoor panel frame
1125	Oven door thermometer & clips	1536	Warming cabinet body	4310	Ash pan door
1155	Oven door spring	1545	Cresting panel	4311	Ash pan door-complete
1159	Right oven door hinge nickel	1551	Right cabinet bracket	4315	Ash pan door flap
1184	1 piece stove top (Oval)	1556	Left cabinet bracket	4369	SweetHeart one piece top
1224	Damper plate weldment (Oval)	1570	Lower cabinet front trim strip	4370	Key plate
1228	Sliding oven damper arm (Oval)	1575	Upper cabinet front trim strip	4405	7 3/4" solid lid
1232	Left or right Oval Split Brick (Oval)	1588	Right cabinet corner	4445	Ash pan
1234	Oval firebrick replacement kit	1592	Left cabinet corner	4449	Oven rack(SweetHeart)
1236	Slider knob	1595	Right crestring corner	4465	6" Dia SweetHeart flue weldment
1237	Upper Right Fire Brick-(Oval)	1600	Left crestring corner	4455	Front base rail
1258	Brick Holder (Oval)	1607	Cabinet door	4460	Base rail right or left
1255	Firebox cast lining - left (Oval)	1609	Cabinet door handle	4523	Splash back
1267	Wood grate frame	1629	Water Tap flange	4536	Warming cabinet body
1268	Wood grate slide	1631	Chrome water tap	4545	Cresting panel
1269	Wood grate pull	1651	Reservoir control lever	4570	Lower cabinet strip
1270	Wood grate complete	1672	Reservoir top frame	4575	Upper cabinet strip
1277	Towel rack (#2 Oval only)	1674	Reservoir lid	4607	Cabinet door
1287	Front surface band (#3 Oval only)	01750	White porcelain repair kit	4672	Reservoir top frame
1289	Wrap around band (#2 Oval only)	01751	Black porcelain repair kit	6029	Ash catch
1297	Reservoir curved band (#3 Oval only)	01752	Almond porcelain repair kit	60505	Reservoir front
1300	Firedoor panel	3599	Heartland nameplate w/clips	60522	Reservoir front insert panel
1307	Firedoor panel frame	4012	Adjustable Base leg	8452	Oven rack (Oval)
1310	Ash pan door	4041	Firebox front	9449	4 position rack support (Oval)
1311	Ash door, flap, spring handle	4045	Cast fire door	60330	4 position level rack
1315	Ash pan door flap	4107	Oven door frame		
1320	Handle-shaker door	4120	Outer oven door panel		
1325	Cast bell damper handle	4220	Firebrick - complete kit		
1330	Bell damper	4221	Firebrick - left(SweetHeart)		
1335	Bell damper tension spring				
1352	Ash clean out door (dual key hole mount)				
1358	Key plate lift handle				