

WIRING DIAGRAM WITHOUT THERMOSTAT

**WARNING:
Electrical Grounding
Instructions**

This appliance is equipped with a three pronged (grounding) plug for your protection against shock hazard and should be plugged directly into a properly grounded three-prong receptacle. Do not cut or remove the grounding prong from this plug.

Though this heater does not require a 120V A.C. supply for operation of the burner, it is recommended as a primary power source to eliminate the need for batteries, which should only be used as a secondary power source during power loss. 120 volt AC power is also required for the optional blower. In case of a power failure, the remote control/thermostat will continue to operate.


CAUTION: Ensure that the wires do not touch a hot surface and are away from sharp edges.

NOTE

4 AA Batteries must be installed into the back up battery compartment however for this unit to operate when power is lost. See battery back up instructions in this manual. The fan will not operate during a power outage.

NOTE

Even if the fan is not purchased with the unit, it is still a good idea to bring power to the receptacle box (provided with the unit) in case the dan is installed at a later date.



installation

OPTIONAL WALL THERMOSTAT

A wall thermostat may be installed if desired. Connect the wires as per the wiring diagrams.

CAUTION
Do not connect the millivolt wall thermostat wires

Note: Preferable if the thermostat is installed on an interior wall.

Regency® offers an optional programmable thermostat but any 250-750 millivolt rated non-anticipator type thermostat that is CSA, ULC or UL approved may be used.

WIRING DIAGRAM WITH OPTIONAL THERMOSTAT

